

Controller Module Replacement





WARNING: CHOKING HAZARD. Small parts. Not for children under 3 years. Adult assembly is required.

NOTE: Refer to Owner's Manual for any addition information.

STEPS:

- Remove Seat per Owner's Manual.
- Disconnect and remove Battery Controller is under Battery.
- Remove Connectors It's recommended to take a picture or make a simple drawing of how Connectors (A) are attched to Controller (B) before removing.
 - **TIP:** A small flat-blade screwdriver may help push in the Connector lock tabs © for easier removal.
 - **TIP:** It may be easier to remove Controller Screws ① first for easier access to Connectors next step.
- Remove two Screws (1) (one on each side of Controller set aside.
- · Remove Controller.
- Position new Controller in same position as original and reinstall the two mounting screws ①.
 - **TIP:** Pre-install Screws partially in Controller before positioning in place.
- Attach all Connectors (A) in same position as original

NOTES:

- Connector with BLUE wire (E) connects into first location.
- Position remaining two Connectors as shown in view F.
- Connectors should 'CLICK' into place.
- Reinstall Battery and Seat according to Owner's Manual.





